

# SFW05-B

REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTA • LISTE DE PIÈCES DE RECHANGE

SFW05-B

PART NO.	DESCRIPTION	DESCRIPCIÓN	BESCHREIBUNG	DÉSIGNATION
SFW05B01-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05B02-1	EXHAUST COVER	CUBIERTA	ABDECKUNG	COUVERCLE
SFW05B03-1	CYLINDER CAP	CILINDRO TAPA	ZYLINDER KAPPE	CYLINDRE BOUCHON
SFW05B04-1	GASKET	SELLO	DICHTUNG	JOINT
SFW05B05-1	SEAL	SELLO	DICHTUNG	JOINT
SFW05B06-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B07-1	SPRING	RESORTE	FEDER	RESSORT
SFW05B08-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B09-1	VALVE	VÁLVULA	VENTIL	VALVE
SFW05B10-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B11-1	COLLAR	COLLARÍN	KRAGEN	COLLET
SFW05B12-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B13-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B14-1	PISTON ASSEMBLY	ASAMBLE DE PISTON	KOLBEN-ZUSAMMENBAU	ENSEMBLE PISTON-COUTEAU
SFW05B15-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B16-1	CYLINDER	CILINDRO	ZYLINDER	CYLINDRE
SFW05B17-1	BUMPER	AMORTIGUADOR	PUFFER	AMORTISSEUR
SFW05B18-1	JOINT GUIDE	CONJUNTO	GELENK	JOINT
SFW05B19-1	BODY	CARCASA	GEHÄUSE	CORPS
SFW05B20-1	SEAL	SELLO	DICHTUNG	JOINT
SFW05B21-1	TRIGGER VALVE HEAD	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLÉE
SFW05B22-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B23-1	TRIGGER VALVE GUIDE	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLÉE
SFW05B24-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B25-1	TRIGGER VALVE STEM	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLÉE
SFW05B26-1	BRACKET	SOPORTE	HALTERUNG	SUPPORT DE FIXATION
SFW05B27-1	SPRING	RESORTE	FEDER	RESSORT
SFW05B28-1	LOCKING WASHER	ARANDELA DE CIERRE	SICHERUNGSSCHEIBE	RONDELLE VERROUILLAGE
SFW05B29-1	TRIGGER	GATILLO	AUSLÖSER	GÂCHETTE
SFW05B30-1	PIN	PASADOR	STIFT	GOUPILLE
SFW05B31-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05B32-1	DRIVER GUIDE	GUÍA	FÜHRUNG	GUIDE
SFW05B33-1	SPRING PIN	RESORTE PASADOR	FEDER STIFT	RESSORT GOUPILLE
SFW05B34-1	FRONT PLATE	PLACA	PLATTE	PLAQUE
SFW05B35-1	FIXED MAGAZINE UNIT	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
SFW05B36-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05B37-1	STOP	TOPPE	PUFFER	ARRÊT
SFW05B38-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05B39-1	MOVABLE MAGAZINE UNIT	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
SFW05B40-1	PIN	PASADOR	STIFT	GOUPILLE
SFW05B41-1	WHEEL	RUEDA	RAD	ROUE
SFW05B42-1	TENSION SPRING	MUELLE DE TENSIÓN	TENSIONSFEDER	RESSORT DE TENSION
SFW05B43-1	FEEDER SHOE	ALIMENTADOR	NAGELSCHIEBER	POUSSOIR
SFW05B44-1	SPRING WASHER	RESORTE ARANDELA	DICHTUNG SCHEIBE	JOINT RONDELLE
SFW05B45-1	NUT	TUERCA	MUTTER	ÉCROU
SFW05B46-1	SUPPORT	SOPORTE	HALTERUNG	SUPPORT DE FIXATION
SFW05B47-1	SCREW	TORNILLO	SCHRAUBE	VIS
SFW05B48-1	PIN	PASADOR	STIFT	GOUPILLE
SFW05B49-1	TORSION SPRING	MUELLE DE TORSIÓN	TORSIONSFEDER	RESSORT DE TORSION
SFW05B50-1	LOCK	TRABAR	VERRIEGELN	VERROUILLER
SFW05B51-1	NUT	TUERCA	MUTTER	ÉCROU
SFW05B52-1	SOFT GRIP SLEEVE	AGARRADERO	GRIFF	GAINÉ DE CUIR
SFW05B53-1	O-RING	SELLO	DICHTUNG	JOINT
SFW05B54-1	END CAP	TAPA	KAPPE	BOUCHON
SFW05B55-1	AIR PLUG	AIRE ENCHUFE	LUFTSTECKER	L'AIR BOUCHON



## B LIGHT WIRE STAPLER

Parts Reference Guide

Guía de referencia de piezas

Pièces Guide de référence

Schematic Drawings Inside  
Plano esquemático en el interior  
Schéma intérieur



Verpa Senco BV  
Pascallaan 88  
8218 NJ LELYSTAD  
The Netherlands

[www.senco-emea.com](http://www.senco-emea.com)

© 2014 by Senco Brands, Inc.

Rev. VS14SFWB04\_25-06-2014

EU DESIGNED PARTS CAN BE DIFFERENT

